

Installation Guide

John Deere Left Hand Utility Step

(PN: 3435)

1. Remove plastic plugs from top two holes on the left side of the frame.
2. Fasten the step bracket to the offset plate using the 3/4" x 2" carriage bolts, lock washers, and nuts.
3. If you have a toolbox mounted in the same location that the step is to be mounted, move it to the lower two holes so it is below the step.
4. Mount the step bracket and offset bracket to the frame of the tractor using the 20mm x 50mm bolts.

