

Instruction Guide

CIH Big M Step for 71, 72 & 89 Series Magnum - (PN: 3314)

- 1. Remove the outer bolt from the top cab step (A) and the inner bolt from the middle step (B).
- 2. Remove the large bolt from the side of clutch housing (C).
- 3. Install the **Big M Step** using the bolts just removed.

Note!

It is also necessary to remove the plastic cover and light fixture to gain access to the clutch housing bolt.

