

1. Remove the original step from the tractor.
2. Fasten the **mounting bracket** to the side of the tractor cab with two 3/8" x 1 1/2" carriage bolts and flange nuts. Use the original bolts in the bottom and rear holes.

3. Insert the **pivot arm** of the **top step section** into the **mounting bracket** and fasten with two 5/8" x 4" capscrews, lock washers and nuts.

4. Fasten the **bottom step section** along the outside of the **top step section** using four 3/8" x 3/4" carriage bolts and flange nuts.

5. Fasten the lower end of the **handrail** to the rear side of the **mounting bracket** with two 3/8" x 1" bolts and flange nuts.

6. Clamp the upper end of the **handrail** to the front side of the fender and drill two 5/16" holes. Fasten with two 5/16" x 1" bolts and flange nuts.

