

# Instruction Guide

## Extend-A-Step for K & M JD Regular Steps - (PN: 3412) For 10-20 and Other Series

1. Position the **Extend-A-Step** to the back side of the **top step segment** and mark holes to be drilled.
2. Center punch the holes that you marked and drill with a 3/8" bit.
3. Position the step and bolt it on with two 3/8" x 1" hex bolts, lock washers and nuts that are provided.

