

Installation Guide

Nite-Gard™ Horizontal Mount (PN: 3242)

1. Find a sturdy horizontal surface to mount the light to. NOTE: It is the customer's responsibility to ensure the surface is strong enough to support the warning light.
2. Use the mount bracket to mark the holes for the mounting bracket.
3. Drill four 13/32" holes for the mounting bracket.
4. Place the mount bracket on the top of the mount surface and the backup plate on the bottom of the mount surface and fasten together using 3/8" x 1 1/2" carriage bolts, lock washers, and nuts.
5. Mount the warning light arm to the horizontal mount bracket using the 3/8" x 1 bolts and flange nuts.
6. Locate the flasher circuit on the tractor.
7. Connect one wire to the flasher circuit and ground the other wire. Be sure to trim the wire on the warning light arm and discard any excess wire.
8. Loosen the knob and extend the light extension to desired position.
9. Re-tighten the knob. Do not over tighten.

