

Instruction Guide

John Deere Open Station Step & Handrail (PN: Step-3424 / Handrail-3343)

1. Remove the original step from the tractor.
2. Fasten the **pivot bracket** to the **mounting bracket** using two 1/2" x 1 1/2" bolts and flange nuts.
3. Fasten the **mounting bracket** to the tractor frame as shown below, using two 5/8" x 1 1/2" carriage bolts and flange nuts.
4. Place the **pivot arm** of the **top step section** between the plates of the **pivot bracket** and secure with two 5/8" x 4" bolts and flange nuts.
7. Attach the **bottom step section** with two 3/8" x 3/4" carriage bolts and flange nuts in the rear holes. Fasten the front holes of the steps, along with the **handrail**, using two 3/8" x 1" carriage bolts and flange nuts.

