

1. Remove the original step from the tractor.
2. Fasten the **mounting bracket** to the side of the tractor cab with two $3/8" \times 1\ 1/2"$ carriage bolts and flange nuts. Use the original bolts in the bottom and rear holes.

3. Insert the **pivot arm** of the **top step section** into the **mounting bracket** and fasten with two $5/8" \times 4"$ capscrews, lock washers and nuts.

4. Fasten the **bottom step section** along the outside of the **top step section** using four $3/8" \times 3/4"$ carriage bolts and flange nuts.

5. Fasten the lower end of the **handrail** to the rear side of the **mounting bracket** with two $3/8" \times 1"$ bolts and flange nuts.

6. Clamp the upper end of the **handrail** to the front side of the fender and drill two $5/16"$ holes. Fasten with two $5/16" \times 1"$ bolts and flange nuts.

