

Lankota, INC.

LAN – EC302

Connect Wiring Harness From Early Model Row Crop Heads To Single Point Combine Hook-Up (Without Hydraulic Deck Plates)

Installation Instructions

LAN – EC302 Parts break down list

		
LAN – PL02	LAN - 175880	LAN – EC300

*** Items are included in bag of hardware**

John Deere and JD are registered trademarks of Deere & Company

EC302 INSTALATION INSTRUCTIONS

1. If header is equipped with the older style **16 PIN** wiring harness which is comparable to the size of your thumb, connect male end of Wiring Harness (**LAN-E1300**) to header wiring harness first. Tighten plastic locking collar.
2. Connect male end of Wiring Harness (**LAN-EC300**) to female end of Wiring Harness (**LAN - EC100**) installed in step 1 or original **31 PIN** connector factory installed on the header. Tighten plastic locking collar.
(See **Figure 1**)



Figure 1

3. Position Multi-Coupler Block (**LAN-PL02**) into combine single point connector block. Secure and lock down handle.
4. Secure any loose parts of connected wiring harnesses to avoid damage during machine operation and transport.

For further information you may contact:

**Lankota Inc.
(866) 526-5682**